





BPW3500

Parts List



Model No. HPP1780-0, BPW3500
IPL No. 192056GS Rev 0 (10/18/2002)

Pressure Washer




Item	Part #	Description	Item	Part #	Description
1	A189641GS	BASE	13	192123GS	KIT,Vibration Mount
2	BB1982GS	BUMPER	14	B4805GS	HOSE
3	63281GS	KEY	15	I87978GS	KIT, Upper Handle Hardware
4	192134GS	KIT, Engine Mounting Hardware	16	192125GS	KIT, Pushnut
5	BB1981GS	HANDLE, Lower	17	192135GS	KIT, Garden Hose Inlet
6	B190293GS	HANDLE, Upper	18	B3858GS	WAND, Quick Disconnect
7	30809GS	GROMMET	19	B1436BGS	GUN
8	192126GS	KIT,Vinyl Cap	20	95458GS	FITTING, Quick Disconnect
9	192129GS	KIT, Lower Handle Hardware	21	192124GS	KIT,Wheel
10	192130GS	KIT, Bumper Mounting Hardware	22	I85805GS	ASSY, Pump
11	B4847GS	KIT, QD Spray Nozzles	23	192136GS	KIT,Thermal Relief
12	192132GS	KIT, Pump Mounting Hardware	24	192168GS	KIT, Chemical Hose
			900	Contact Engine Manufacturer

Items Not Shown

Part #	Description
191806GS	MANUAL, Owners
192056GS	MANUAL, Parts List
MS6669	MANUAL, Engine
192139GS	KIT, Decals
191922GS	KIT, Maintenance
87815GS	GOGGLES
BB3061BGS	BOTTLE, Oil, Engine

Kits include all parts shown in frames.


Pump



Item	Part #	Description
0	I87263GS	ASSY, Pump
1	I01B2327GS	PLUG
2	I00B2327GS	O-RING
3	I02B2327GS	VALVE
4	I03B2327GS	O-RING
5	I04B2327GS	PLUG
6	I05B2327GS	O-RING
7	I06B2327GS	RING, Support
8	I07B2327GS	GASKET
9	I08B2327GS	GUIDE, Piston
10	I09B2327GS	O-RING
11	I10B2327GS	GASKET
12	I86381GS	SEAL
13	I12B2327GS	SCREW
14	I13B2327GS	SUPPORT, Bearing
15	I32B2327GS	SHIM
16	I14B2327GS	O-RING
17	I86382GS	BEARING
18	I86383GS	HOUSING, Pump
19	I17B2327GS	CAP, Oil
20	I18B2327GS	NUT
21	I19B2327GS	WASHER
22	I20B2327GS	PISTON

Item	Part #	Description
23	I21B2327GS	SPACER
24	I22B2327GS	O-RING
25	I61B2327GS	RING
26	I23B2327GS	GUIDE, Piston
27	I24B2327GS	PIN, Piston
28	I86384GS	ROD, Connecting
29	I18B2126GS	COVER
30	I343501GS	SCREW
31	I86385GS	PLUG
32	I34B2327GS	O-RING
33	I16B2126GS	O-RING
34	I42B2126GS	SCREW
35	I50B2126GS	FLANGE
36	I39B1410GS	O-RING
37	I38B1410GS	SEAL
38	I37B1410GS	BEARING
39	I52B2126GS	SCREW, Grub
40	I86386GS	SHAFT
41	I36B2327GS	PLUG
44	I39B2327GS	HEAD, Pump
45	I59B2327GS	WASHER
46	I40B2327GS	SCREW

Unloader



Item	Part #	Description	Item	Part #	Description
0	153B2126GS	UNLOADER, Complete	21	228B2327GS	HOUSING, Valve
1	210B2327GS	TAIL, Hose	22	229B2327GS	RING
2	231B2327GS	O-RING	23	230B2327GS	WASHER
3	211B2327GS	BALL, Stainless	24	232B2327GS	PISTON, Lower
4	212B2327GS	SPRING	25	234B2327GS	O-RING
5	213B2126GS	BODY, Injector	26	233B2327GS	GUIDE, Piston
7	215B2327GS	NUT, Injector	27	235B2327GS	O-RING
8	137B2327GS	O-RING	28	241B2327GS	FITTING, Suction
9	216B2327GS	SPRING	29	240B2327GS	O-RING
10	217B2327GS	PLUNGER	30	239B2327GS	WASHER
11	218B2327GS	O-RING	31	238B2327GS	FITTING, Bypass
12	220B2327GS	PLATE, Spacer	32	237B2327GS	WASHER
13	221B2327GS	SPRING	33	236B2327GS	BOLT, Inlet
14	222B2327GS	SPRING, Spacer Plate	34	248B2327GS	PLUG
15	219B2327GS	PISTON, Upper	35	155B2327GS	SCREW
16	223B2327GS	PIN	36	246B2327GS	NUT
17	224B2327GS	RING	37	245B2327GS	KNOB
18	225B2327GS	O-RING	38	243B2327GS	HOUSING
19	226B2327GS	BOLT, Inlet	39	244B2327GS	PIN
20	227B2327GS	WASHER	40	242B2327GS	GUIDE, Spring